

TRAILER BODY

(DRAWBAR)

LOAD CELL

(DRAWBAR - PLAN VIEW)

(EQUAL DISTANCE)

(EQUAL DISTANCE)

(DRAWBAR)

LOAD CELL

(DRAWBAR - SIDE VIEW)

(EQUAL DISTANCE)

(EQUAL DISTANCE)

**PACIFIC SCALES**  
WEIGH AHEAD

www.pacificscales.com.au

TITLE: FARM TRAILER DRAWBAR

Phone = (03) 6265 3844

DRAWN BY:

SCALE

DATE

DWG No.

E - Mail = info@pacificscales.com.au

N.T.S

COPYRIGHT

PSI 4-1